


## **Licence Keys and Configuration**

## **iVN** Licence

When iVN is launched for the first time you will be taken to the Account tab and prompted to log in with username and password




If you are a commercial customer or new trial then you will have been set up with an account on the licence system and can log in with your email address and password that use normally use on www.iesve.com.


If you do not have this access yet then please contact your Account Manager or else <a href="keys@iesve.com">keys@iesve.com</a> to request it.



When a valid licence is entered the application will show the status of your subscription.



You can now proceed to the Welcome section of the Homepage and continue to use the software.



## **VE Licence**

When VE is launched for the first time it will open with no applications loaded. You are required to request the VE\_Kernel licence in order to be able to run Energy simulations from iVN.


This can be done in VE as follows:

Click Tools >> Preferences and on General tab ensure 'Use legacy licence activation' is ticked, Next click Help >> Request Licence, complete the form and click Send Request.

www.iesve.com



Note this will send an email to <a href="keys@iesve.com">keys@iesve.com</a>, our team will then check your account with the Account Manager and when verified send back the licence key for VE Kernel



www.iesve.com



## **iVN & VE Configuration**

The final step required for Energy simulation is to connect the iVN to point to VE with energy simulation licence.

Do this in iVN from the Settings menu on the Home-page



Click browse icon on VE Location and then browse to the VE 2019.0.0.0 installation at C:\Program Files (x86)\IES\VE 2019\apps

When the path is set correctly and accepted then the text is grey



www.iesve.com